



## **Content List**

| QTY | DESCRIPTION  |
|-----|--|
| 1   | 50Ltr Yellow PVC Spill Bag                                     |
| 10  | GP Poly Pads , 48x43cm H/W, Dimpled & Perforated [ES-PPGP-400] |
| 1   | Floorsweep 5KG [ES-A-FS-05]                                    |
| 1   | GP Grey Absorbant Socks 1.2mx75mm<br>[ES-SOGP-75-1.2]          |
| 1   | GP Grey Absorbant Pillow 45x45cm<br>[ES-P-GP]                  |
| 1   | Pair of Nitrile Gloves [RNF15L]                                |
| 3   | Contaminated Waste Bags - 450x750mm<br>[ES-WB]                 |
| 1   | Dustpan & Brush  |
| 1   | Spill Kit Sticker  |
| 1   | Spill Kit Instructions   |

**50L** General Purpose Kit [ES-SK50G]

**50L** General Purpose REFILL Kit [ES-SK50G-R]

## SPILL KIT

## **50 Litre General Purpose Spill Kit**

FOR USE WITH NON-AGGRESSIVE LIQUIDS

## **Directions for Use**

- 1. Assess the liquid that was spilt before applying absorbent (consult SDS for safety precautions).
- 2. Contain the spill using the absorbent or containment sock.
- 3. Apply absorbent to cover spill.
- 4. The mix of absorbent and the spill should apprear dry, if not, apply more absorbent to cover spill.
- 5. Using a stiff broom, sweep absorbent over the spill area.
- 6. If the mix does not appear dry or there remains an oily film on the surface, apply additional absorbent.
- 7. Use pads to wipe clean any area or equipment not cleaned by the absorbent.
- 8. Dispose of in accordance with local government regualtions.
- 9. Complete an incident report and file.
- 10. Re-stock kit with replacement stock.

E&OE | 27.04.2021

